# Betty ^{TK2}
Thau & Kallio
2020

D: 48cm/18.9in
Seating D: 42cm/16.5in.

W: 51cm/20.1in
Seat H: 47cm/18.5in

H: 77cm/30.3in

Betty ^{TK2}
Thau & Kallio
2020

Product description
Dining chair

Environment
Indoor

Material
Lacquered or Oiled solid wood and formpressed veneer. This product has not been treated with any biocides.

Production process
The chair is made from solid wood and formpressed veneer.

Gliders
Felt gliders installed as standard.

Stacking quantity
8 chairs

Dimensions
H: 77cm/30.3in, W: 51cm/20.1in, D: 48cm/18.9in, Seating D: 42cm/16.5in, Seat H: 47cm/18.5in

Packaging dimensions
H: 86cm/33.9in, W: 53.2cm/20.9in, D: 51.7cm/20.4in.

Colli quantity
1 (2 pcs)

Weight
Product: 4 kg
Incl. packaging: 7.5 kg

Country of origin
Latvia

Certifications

EU Ecolabel
www.ecolabel.eu
EU Ecolabel: DK/049/002

**Strength, durability and safety testing**
The chair is tested for strength, durability and safety according to EN 16139 level 2 - Extreme use.

Cleaning instructions
Please download our Material Care & Cleaning instructions through www.andtradition.com

➔ Stock items
Black
Oak
Smoked Oak

➔ Black
Lacquered ash

➔ Oak
Lacquered oak

➔ Smoked Oiled Oak

Related products

| TK1 | TK3 | TK4 | TK5 | TK7 | TK8 | TK9 | TK10 | TK11 |

&Tradition®

TK2

Recycling
& Disassembly

Betty ^{TK2}

RECYCLING

The Betty chair is built to last, and we hope that your Betty will serve you for many years. The chair is made from solid wood and wood veneer, and can be easily separated from its base. All metal and wooden parts can be separated and delivered to a suitable recycling station.

SPARE PARTS

To purchase spare parts for your Betty chair, please write to our sales support team at info@andtradition.com with your query.

5 YEAR WARRANTY

&Tradition provides a 5-year warranty with every Betty chair, which covers faults which were present at the time of purchase, or which have occurred as a result of a manufacturing defect. The warranty is valid from the date stated on the original invoice.

DISASSEMBLY

Screws - Steel

Disassembling of Betty chair

1. Unscrew the bolts located inside the frame of the seat. This can be done with a socket wrench.

2. Remove the gliders.

Gliders - PE & felt

&Tradition ®